



arancia rechargeable



Recharge your mobile information-center via any USB-connection over 500 times and save hundreds of batteries to protect our environment. The arancia rechargeable is your reliable companion for all outdoor activities

arancia/AltiSki with 26 functions:

Time-Mode: Time, date, alarm, countdown, stopwatch, stopwatch-memory, 2nd time-zone.

Altimeter-Mode: Altitude [m, ft] with LOCK-function, maximum altitude, barometric pressure [mbar, inHg].

Descent-Mode: Descent [m, ft], descent-rate, maximum descent rate, daily descent, total descent.

Ascent-Mode: Ascent in [m, ft], ascent-rate, maximum ascent rate, daily ascent, total ascent.

Runs-Mode: Runs, daily runs, total runs.

Temperature-Mode: Temperature [°C, °F], maximum temperature, minimum temperature.

Laden Sie ihr mobiles Info-Center über jede USB-Verbindung. Bei über 500 möglichen Ladevorgängen sparen Sie hunderte Batterien und schonen so die Umwelt. Die arancia rechargeable ist Ihr zuverlässiger Begleiter bei allen Outdoor-Aktivitäten.

arancia/AltiSki mit 26 Funktionen:

Zeit-Modus: Uhrzeit, Datum, Alarm, Countdown, Stoppuhr, Stoppuhr-Speicher, 2te Zeitzone.

Höhenmesser-Modus: Aktuelle Höhe mit LOCK-Funktion, maximale Höhe, Barometer.

Höhenmesser/Abstieg: Abgestiegene Höhenmeter, Abstiegsgeschwindigkeit, maximale Abstiegs-geschwindigkeit, Abstieg pro Tag, Abstieg total.

Höhenmesser/Aufstieg: Aufgestiegene Höhenmeter, Aufstiegsgeschwindigkeit, maximale Aufstiegs-geschwindigkeit, Aufstieg pro Tag, Aufstieg total.

Abfahrtszähler: Anzahl der Abfahrten, Abfahrten pro Tag, Abfahrten total.

Temperatur-Modus: Aktuelle Temperatur, maximale Temperatur, minimale Temperatur.

**other MICROSPORT products/
weitere MICROSPORT Produkte**

**Altimeter Watches Höhenmesser
elements/Outdoor Computer**

Altimeter, Barometer, Compass, Thermometer.
verde rechargeable

Mobile weather station with altimeter.

**Speedometer/Tachometer
In-Line Skate Speedometer**

Just replace one wheel and off you go!

Jogging/Walking Speedometer

Speed, distance and heart rate in one unit.

Snowsport Speedometer

Radar continuously measures speed and distance.

Airtime Sensor for Snowboards and Skis.

Measures duration of your jump.

PowerPack

Mobile, solar power-supply for your security.

Tent Illumination/Zeltbeleuchtung

MICROSPORT Outdoor Electronics, Wearable Electronics, Wireless Communication, OEM

Grüntal 10a, 81925 München, Germany, phone +49 89 30725599, fax +49 89 30725598,
www.microsport.de, info@microsport.de

MICROSPORT[®]
OUTDOOR ELECTRONICS

RECHARGEABLE



Environment-friendly Altimeter/Barometer Watch for all mountain activities.